Basic Programming for DG35

2580

2580

RELAY 1
(80 users)

Add a pin too
Relay 1

Enter user code
*001 to *080

Enter 4 digit
Pin not

2580

#

Relocking time
RELAY 1

*300
Followed by
Number of seconds
01 to 99
Latching
00

"BEEP"

#

Changing master code

*000

New master code
4 digits

#

"BEEP"

DELETE User Code

*500

Enter user code
To be deleted

"BEEP"

#

RELAY 2
(80 users)

Add a pin too
Relay 2

Enter user code
*081 to *160

Enter 4 digit
Pin not

2580

#

Relocking time
RELAY 2

*400
Followed by
Number of seconds
01 to 99
Latching
00

"BEEP"

#